



Texas  
Agricultural  
Extension  
Service

November, 1988

Southern  
Regional  
Aquaculture  
Center



# Site Selection of Levee-type Fish Production Ponds

Thomas L. Wellborn\*

Considerable thought and planning should go into selecting sites for commercial fish production ponds. Construction costs, ease and cost of operation, and productivity can be greatly affected by the site selected.

Selection of pond sites on flat land would seem to be a simple matter but many factors are involved. These alternatives must be considered, or you may find the cost and problems associated with production prohibitive with respect to profits.

## Water availability

Water for filling levee-type ponds must come from a well, spring, reservoir or stream since there is no watershed for runoff water to enter the pond. Thus, one of the first considerations in selecting a site for commercial fish ponds is to make sure that an adequate supply of suitable quality water is available for the size farm planned.

Usually one well with a capacity of 2,000 to 3,000 gallons per minute (gpm) is adequate for four 20-acre

ponds, or a minimum of 25 gpm per acre of pond surface. There must be enough water available to fill the pond completely within 10 days, otherwise problems with vegetation and water quality management will occur. Table 1 gives the time required to pump different volumes of water at different pumping rates.

A local well drilling company, a ground water geologist, or the closest office of the U.S. Geological Survey should be able to tell you if a well of the desired capacity can be developed at the site. Information on the quality of ground water at the site should be available from the U.S. Geological Survey or local ground water geologist.

## Water sources

Water for levee ponds for commercial fish production can come from a well, spring, stream or reservoir. Of the four choices, a well is usually the best for several reasons. A spring is almost as good. Streams and reservoirs should be used only as last resorts because they usually contain various species of wild fish that can get into the pond and cause severe management problems. Streams and reservoirs can also become con-

taminated with pesticides or industrial chemicals that could kill fish. During droughts water levels become so low in the streams and reservoirs that they can no longer be used as sources of needed pond water. Wild fish in streams and reservoirs serve as constant sources of reinfection with various infectious diseases. The quality of water in streams and reservoirs can change enough during droughts or floods as to be unusable at those times.

If a stream or reservoir **must** be used as a source of water for commercial fish ponds, be aware of potential problems. Appropriate actions may need to be taken to avoid fish loss or additional expenditure of funds.

## Soil characteristics

The soil must hold water, so clay-type soils are desirable. Take soil cores at various places around the site to insure adequate clay is present to prevent excess seepage. The local Soil Conservation Service Office can assist you. Ponds can be built in soils that have high percolation rates if they are lined with a layer of packed clay or plastic, but costs are almost prohibitive.

\* University of Florida.

**Table 1. Time in hours required to pump different volumes of water in acre feet at four different pumping rates.**

Pumping Rate	Volume in Acre Feet <sup>1</sup>			
	1	5	10	70 <sup>2</sup>
	Hours			
500 gpm	10.9	54.3	108.6	760 (31.6) <sup>3</sup>
1,000 gpm	5.4	27.0	54.3	380 (15.8) <sup>3</sup>
2,000 gpm	2.7	13.5	27.2	190 (7.9) <sup>3</sup>
3,000 gpm	1.8	9.0	18.1	127 (5.3) <sup>3</sup>

<sup>1</sup> 1 acre foot = 325,850 gallons = surface acre that is one foot deep.

<sup>2</sup> The number of acre feet of water in a pond with 17.5 surface acres with an average depth of 4 feet.

<sup>3</sup> Number of days required to pump that volume of water.

## Topography

The topography or lay-of-the-land determines the amount of dirt that has to be moved during pond construction. Pond construction on flat land requires less dirt moving than building on rolling or hilly land. Levee-type ponds built on flat land usually require about 1,100 to 1,200 yards of dirt to be moved per acre, although the actual amount of dirt that must be moved can vary greatly from this figure.

## Wetlands

Before selecting the site be sure the land is not classified as a wetland. A permit is required from the Corps of Engineers before clearing or building on wetlands. In some states, particularly Florida, permits are needed from one or more state agencies before any clearing or building can take place on wetlands.

Wetlands are defined as: "Those areas that are inundated or saturated by surface or ground water at a frequency and duration to support, and that under normal conditions do support, a prevalence of vegetation typically adapted for life in saturated

soil conditions. Wetlands generally include swamps, marshes, bogs and similar areas."

## Draining

For management purposes and for harvesting you must be able to drain the ponds, and the site should be selected with this in mind. You must be able to drain the ponds by gravity flow, and insure that draining your ponds will not cause flooding on a neighbor's land or block the drainage from a neighbor's land.

## Flooding

Make sure the site under consideration is not subject to periodic flooding. This can be done by checking with the local U.S. Geological Survey Office or Soil Conservation Service Office.

## Utility right-of-ways

Before building ponds over pipe lines or under power lines, check locations of right-of-ways with the utility company first to avoid possible legal problems later.

## Pesticides

Check the soil for pesticide residues if row crops were ever grown on or adjacent to the site being considered. There are three areas within a site that must be checked for pesticide residue levels. These are:

- low areas where run-off collects;
- any area where spray equipment, either aerial or ground, was filled with pesticides; and
- any area in the site where pesticides were disposed of or were stored.

Chlorinated hydrocarbon pesticides--particularly toxaphene which was widely used in the past as an insecticide in row crop farming--are long lasting in the soil. High soil concentrations of toxaphene in ponds can harm fish either through direct, acute toxicity or by chronic toxicity due to bioaccumulation. Observation seems to indicate that soil concentrations in excess of 0.5 parts per million (ppm) or milligrams per liter (mg/l) can be harmful to fish. Most chlorinated hydrocarbon pesticides are tied up in the top 2 to 4 inches of soil, depending on the type of farming practices used. Samples for analysis should be taken at a depth not to exceed 4 inches. If the top layer of soil contains high levels of pesticides while the soil deeper than 4 inches is pesticide free, the top layer of contaminated soil can be moved off and incorporated in the outside levees only. Do not use the contaminated soil in outside levees if planned expansion will utilize these outside levees as future inside levees.

Analysis of soils for pesticide residues can be done by commercial analytical laboratories or, in some states, by your State Chemical Laboratory. Check with your local county Extension agent to see if a state agency offers this service.

This publication was supported in part by a Grant from the United States Department of Agriculture, Number 87-CRSR-2-3218, sponsored jointly by the Cooperative State Research Service and the Extension Service.

Educational programs conducted by the Texas Agricultural Extension Service serve people of all ages regardless of socioeconomic level, race, color, sex, religion, handicap or national origin.

Issued in furtherance of Cooperative Extension Work in Agriculture and Home Economics, Acts of Congress of May 8, 1914, as amended, and June 30, 1914, in cooperation with the United States Department of Agriculture. Zerle L. Carpenter, Director, Texas Agricultural Extension Service, The Texas A&M University System.